

USB Hub Installation Guide

SKU: ACC-BTUH





This guide is specifically for installation with a 1708 style cable and Samsara Camera.

Purpose of the Samsara USB Hub:

- Electrical support
- Engine data support
- USB splitter functionality




4 pieces of hardware to install

	PRODUCT	QTY	COMPONENTS
	VG34 Vehicle IoT Gateway	1	Telematics device with 1 USB port and 1 power port.
	Samsara USB Hub SKU: ACC-BTUH	1	USB Hub with three USB ports and 1 USB cord - also has a required power pass through component.
	CM3X [Front or dual-facing] AI Dash Cam	1	[Front or dual-facing] 1 USB cord for power and data transfer.
	1708 style VG cable 6 pin SKU: CBL-VG-1708 9 pin SKU: CBL-VG-1708-9P	1	[6 pin or 9 pin cable] 1708 style cables have a USB cord for data transfer and a power plug.


Installing the USB Hub

5 components need to be plugged in:



1 & 2

Insert the 1708's USB cord and the Camera's USB cord into the USB Hub.



3

Insert the 1708's power plug into the USB Hub.



4 & 5

Insert the USB Hub's USB and Power plugs into the VG34